



EKSELANS BY ITS

# USER MANUAL

## SWP 5/9/26

334001/334002/334003

Switches PoE for Access Points




V03


# INDEX

Hardware SWP 5 /9/26.....	3
Installation diagram.....	3

## Hardware SWP 5 /9/26



SWP 5



SWP 9



SWP 26

- **DC:** DC power connector.
- **PoE Lan:** Connection for Wireless Access points compatible with IEEE802.11af/at (48Vdc).
- **UpLink:** Connector for the mainstream bandwidth.
- **SFP (only SWP 5):** SFP connector for the fiber adapter. Connection for the mainstream bandwidth. If connected the RJ45 Uplink will not work.

## Installation diagram

The equipment is completely transparent, without configuration.

