
# SHAKS S3b

Quick Guide v1,0

This is a quick guide for setup SHAKS. For the full user manual, please visit our website (http://en.shaksgame.com). If any question, please contact us (https://shaks.channel.io)





#### Overview of LED Signals



#### **Button / Key Layout**

LED #1,2 show connection and battery charging status and LED #3,4 show gamepad mode.





# SHAKS GameHub App (Only for Android)

- \*\* Please search for SHAKS Game Hub in Google Playstore or download and install app from the QR code.
- \*While you do not need to install app on your mobile phone to use the gamepad, we highly recommend so you can benefit from the following features from the mobile app:
- Check gamepad kevs and buttons
- Touch mapping (convert touch keys into controller keys)
- Turbo, sniper, mouse
- Firmware upgrade



\*\* NOTE ) When upgrading firmware for gamepad, please connect your gamepad using USB cable to avoid power shortage.

### How to charge

Charge battery by charging cable from a computer or USB power charging device. You can play S3b while charging.

When battery low	When charging	When charged fully
(A) fast blinking	slow blinking	stops blinking

How to 3 step Setup (Refer video tutorial: https://bit.ly/3aaWUn1)

- 1 Find gamepad mode for your device in the table
- 2 Change mode of gamepad by key or press "Hot Key\*"
- 3 Pair Bluetooth, and enjoy!

Your Device	Gamepad Mode	Bluetooth Name	Hot Keys *
Android, Fire TV, Fire stick	= N=	SHAKS S3b xxxx Andorid	<b>▲</b> + L1
Windows, Mac, Chrome		SHAKS S3b xxxx Win-Mac	A + Select
iPhone, iPad		Xbox Wireless Controller	🕭 + Start
Android (Mapping)	Naff	SHAKS S3b xxxx mapping	🕭 + L1 + Select

### Step 1: Turn Power On

- Press 🛦 for 3 seconds.
- \*\* When the gamepad is turned on by pressing (a) button, default is Android mode to pair change mode according to above table, And follow step 2 based on the device you wish to connect,
- \* After initial set up is complete, the gamepad will remember your device to connect automatically.

# Step 2: Connecting with an Android Device (Phone, Tablet, TV Box, Fire TV, Fire Stick)

- Mode Set Up: When the power is off, press [▲+ L1] button simultaneously for booting.
- Check Mode: Check if LED signals #1 and #2 are off, #3 and #4 are on. If yes, it is connecting to an Android device. If not, please repeat step above.
- Bluetooth Pairing: Press [Select + Start] simultaneously for 3 seconds. On your device, select "SHAKS S3b xxxx Android". Once paired, gamepad will remember and will reconnect automatically.
- \*\* NOTE ) If you wish to play on mapping mode on the same Android device, please delete "SHAKS S3b xxxx Android" and follow "OPTIONAL STEP: Playing on Mapping Mode (for Android only)" to set up and reconnect the Android device.

## Step 2: Connecting with a Windows, Mac OS, Chromebook

- \* Please download utility on our website, (https://en.shaksgame.com/app/)
- Mode Setting: When the power is off, press [▲) + Select] button simultaneously for booting.
- Check Mode: Check if LED signals #1, #2, #3 are off, only #4 is on. If yes, it is connecting to a Windows /Mac OS, Chromebook device. If not, please repeat step above.
- Bluetooth Pairing: Press [Select + Start] simultaneously for 3 seconds. On your device, select "SHAKS S3b xxxx Win-MAC". Once paired, gamepad will remember and will reconnect automatically.
- \*\* Recommended to use Windows 10 or later. If you are using Windows 7, please install "Xbox 360 driver" driver first on your PC that you can find on our website.
- \* Recommended to use Big Sur or later of Mac OS
- \*\* While it is not required, we highly recommend to download utility application on our website (https://en.shaksgame.com/app/) on your device. You can use our advanced features such as turbo and sniper including FW update from the app!

#### Step 2: Connecting with iOS Device (iPhone or iPad)

- Mode Set Up: When the power is off, press [♠+ Start] button simultaneously for booting.
- Check Mode: Check if LED signals #1, #2, #4 are off, only #3 is on. If yes, it is connecting to an iOS device. If not, please repeat step above.
- Bluetooth Pairing: Press [Select + Start] simultaneously for 3 seconds. On your device, select "Xbox Wireless Controller". Once paired, gamepad will remember and will reconnect automatically.
- \* Recommend OS version: iOS 13 or later.

### Step 2: Playing on Mapping Mode (for Android only)

- Mode Setting: When the power is off, press [ 🛦 + L1 + Select] button simultaneously for booting.
- 2 Check Mode: Check if all LED signals are off. If not, please repeat step above.
- Bluetooth Pairing: Press [Select + Start] simultaneously for 3 seconds. On your device select "SHAKS S3b xxxx Mapping". Once paired, gamepad will remember and will reconnect automatically.
- A Now you are ready to play games with mapped keys on your device! Only when you are in the mapping mode you can use touch keys as gamepad controllers that you set up.
- \*\* NOTE ) If you wish to play on non-mapping mode on the same Android device, please delete "SHAKS S3b xxxx Mapping" and follow "Step 2: Connecting with an Android Device (Phone, Tablet, or TV Box)" to set up and reconnect the Android device.

# Wired connecting with a USB Cable for Windows, Android

- Mode Set Up: When the power is off, press start button and connect USB cable to your device.
- 2 Check Mode: Check if all signals are off while **a** button is on.
- \*\* Recommended to use Windows 10 or later. If you are using Windows 7, please install "Xbox 360 driver" driver first on your PC that you can find on our website.

#### Reset & Initializing to recover setup process

If any issue during setup, please reset gamepad and your device as below and try again the step. SHAKS works like a 4 different gamepad, so, connection might be confused across those 4 modes.

- 1 Press "Select+Start" for 5 second longer to delete the profile stored in that mode.
- 2 On your device's Bluetooth setting, delete all paired profile.
- Booting your device again to confirm all cached log deleted

#### Four the information,

- Reset key on gamepad is powered off by force in any emergency case. Profile stored is not deleted.
- At any stage, you can go pairing status by pressing "Select+Start".
- The last paired profle will be tried to re-connect. If fail, next one is being tried in a sequerce.
- "Cached log data" can be cleared by OS by 2-5 minutes automatically. You can wait this auto
  -clearing process. But recommend to do above #3

#### **How to Customize Option Button**

- Option button (O) is set at default as a mouse.
- If you wish to change the option button into another feature besides mouse, run the app on your device. Go under "Setting > Function Key Setting" to choose from:

Features	Wireless BT Mode				Wired Vinnut
	Android	Windows	MFi(iOS)	Mapping	Wired Xinput
Virtual Mouse	Yes				
Turbo	Yes	Yes	Yes	Yes	Yes
Sniper	Yes	Yes	Yes	Yes	Yes
Camera	Yes				
Call/Media Button	Yes				

\*\* Customization of option button is not supported in iOS. We are developing now. Please check back at our website in '21 Q1 for updates,

# How to use Virtual Touch (Mapping) Features

- 1 Firstly, from Google Play, download SHAKS GameHub App.
- 2 Pair your gamepad in Touch mode, refer above "Playing on Mapping mode"
- 3 Go to GameHub App and make sure the pad is connected properly
- 4 At the bottom of the SHAKS App, click

  Mapping Service > Add New Game > Click the game you want to play
- After following the guide on the screen, refer video guide: https://bit.ly/395DW1K

### How to play a few game, example

- Genshin Impact, Roblox, Battleground, League of Legends Wild Rift, Lineage M
- : Possible to play using Mapping feature in SHAKS GameHub App, not compatible in iOS
- Fortnite, FiFA, Slam Dunk, Asphalt, etc.: Compatible in all OS, modes
- COD (Call of Duty) Mobile
- : Playable in iOS immediately, for Android, playable after changing gamepad ID to "Xbox Wirelesss Controller" in SHAKS GameHub App

For more information, please contact us (https://shaks.channel.jo).